

# Installation Instructions for PER FIT® NWTU Cable Connectors



NWTU Body



Hub



Hub Nut

JACKET STRIP LENGTH	
Hub Size (inches)	Strip Length (inches)
1/2	7/8
3/4	7/8
1	1-1/4
1-1/4	1-1/4
1-1/2	1-1/2
2	2-1/8
2-1/2	2-3/16
3	2-3/16
3-1/2	2-3/8
4	2-3/8

1. Remove enough jacket and armor from the end of the cable to allow wire leads long enough to make connections to equipment.
2. Remove sufficient amount of jacket to allow for making a good grounding bond of the armor to connector.
3. OMIT THIS STEP IF NOT USING SLEEVE!\* Slip heat shrinkable sleeve over cable before installing the connector into the equipment. **Do Not** apply heat to sleeve at this time.
4. Screw connector body onto the cable making sure it is tight enough to make a good bond.
5. Without removing the male hub and hub nut from connector, loosen the hub nut and screw the male hub into a threaded entrance on the equipment. With channel locks tighten hub and then tighten hub nut on connector.
6. OMIT THIS STEP IF NOT USING SLEEVE! Slip heat shrinkable sleeve over cable and connector and apply heat to shrink the sleeve.

\*Note: Heat shrinkable sleeves only protect the connector from corrosives, it does not make this connector water tight.